



G Stone Ltd use Correx (corrugated plastic sheets) to make a template, or pattern, for your final worktops. Templating should only take 1-2 hrs (longer for larger or more complex projects). However there are a few things that you can do prior to templating to ensure things run smoothly and unnecessary delays are avoided.

Unit 7B, Robert Way,
Wickford, Essex SS11 8DD

Tel: 01268 766700
Fax: 01268 766738
Email: info@gstoneltd.co.uk
www.gstoneltd.co.uk

1. Ensure that all base units are fitted and fixed, that they are level to within 3mm, that all end panels are in place and all temporary work surfaces have been removed.

2. Ensure that all appliances, hobs, sinks taps and other hardware are on site.

3. Ensure that all surfaces are completely clear of appliances and other items.

4. When our templater visits please be prepared to discuss the following:
- Location of joins - if any
- Location of sinks, drainer, taps etc
- Additional splash back, upstands, window cills or edge detail not on original order
- Any other requirements or queries you might have

5. Deposit of 40% of total order is paid.

PLEASE NOTE: G Stone Ltd does not accept any liability for kitchen units that are not level or walls that are not square/plumb which result in our final installation not being 100% level/square. Any adjustments are the responsibility of the customer/contrator and should be completed prior to final fit. Please make our templater aware of any such adjustments before he starts templating your installation.

G Stone Ltd do not undertake any electric, plumbing or gas installations, carpentry, plastering or decorating. Necessary arrangements should be made with the relevant contractor prior to or post fit.

Please allow 7-10 working days from order to fit. A full version of our terms and conditions can be viewed on our website @ www.gstoneltd.co.uk. Should you have any queries please do not hesitate to call us.